



# ControlHoist 2.0

## STANDARD

INSTALLATION INSTRUCTIONS

AND

USER GUIDE

**Model CSJ & CSH**

Industrial Duty

BELT DRIVE

Jackshaft

Jackshaft with Chain Hoist

Special Application Jackshaft

**-NOT FOR RESIDENTIAL USE-**

**-FOR INDOOR USE ONLY-**

**IMPORTANT:**

PLEASE READ THESE INSTRUCTIONS BEFORE STARTING INSTALLATION. IT IS IMPORTANT THAT THIS OPERATOR BE INSTALLED CORRECTLY IN ORDER TO ACHIEVE SAFE AND PROPER OPERATION.

THIS OPERATOR HAS BEEN SUPPLIED FROM THE FACTORY WITH CONSTANT PRESSURE TO OPEN AND CLOSE. IF OTHER WIRING TYPES ARE REQUIRED, A PHOTO ELECTRIC CONTROL MODEL OSE-S5000 BY VITECTOR FRABA, MODEL HAE00056 BY LINEAR CORP, OR MILLER ELECTRIC REVERSING EDGE MODEL ME WITH BLUE COLOR BAND IS REQUIRED.

**SAVE THESE INSTRUCTIONS**

**INSTALLER: ATTACH THIS BOOKLET TO WALL**

**NEXT TO PUSH BUTTON.**

## **LIMITED WARRANTY**

Raynor warrants the electrical operator and component parts for two (2) years against defects in material and workmanship.

Raynor warrants the electrical operator and component parts against defects in material and workmanship for three (3) years, on the operator only, when purchased with any model of Raynor commercial sectional or rolling door.

Under the terms of this limited warranty, for any operator components that are found to be defective upon inspection by authorized Raynor personnel, Raynor will, at its option, repair or replace the defective door components. Labor charges for installations or repairs shall be the responsibility of the consumer and must be performed by an authorized Raynor Dealer. **This warranty applies only to doors that are professionally installed by an authorized Raynor Dealer.**

This warranty extends only to the original purchaser. This warranty is not transferable.

**This warranty does not apply to any damage or deterioration caused by abuse or failure to provide reasonable and necessary maintenance.**

Raynor shall not be liable for any consequential or incidental damages.

**ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, ARE HEREBY EXPRESSLY EXCLUDED.**

Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above limitation or exclusion may not apply to you.

Claims for defects in material and workmanship covered by this warranty shall be made in writing with proof of purchase to the dealer from whom the product was purchased or call Raynor at 1-800-4-RAYNOR within the warranty period. Raynor may choose to have the product returned for inspection.

This warranty gives you specific legal rights. You may also have other rights, which may vary from state to state.

## **SPECIFICATIONS**

The Raynor ControlHoist Standard Jackshaft type electric operator is designed for use on commercial and industrial size sectional overhead doors and rolling doors only.

### **HEADROOM REQUIREMENT**

Side mount below door shaft, no additional headroom required. Operator mounted above door shaft, requires 32 inches above hardware headroom. See Fig. 1, Page 4.

### **SIDE ROOM REQUIREMENT**

Requires 20 inches of side clearance from jamb. See Fig. 1, Page 4.

### **DOOR TYPE**

For use on lift clearance and vertical lift sectional over-head doors requiring over 30 inches of headroom, and rolling doors.

### **REDUCTION**

V-belt drive from motor to full ball bearing power train with additional chain and sprocket reduction.

### **DOOR TRAVEL**

Operator to move door 6 to 12 inches per second, depending on door size, sprocket reduction and track type.

### **FREQUENCY OF OPERATION**

Will handle up to 30 cycles per hour or 300 cycles per day.

### **MOTOR**

Continuous duty rated, 1725 RPM.

### **CONTROL**

24 volt secondary control circuit as standard.

### **ADJUSTABLE FRICTION CLUTCH**

Provided to protect door and operator if door movement is obstructed.

### **OVERLOAD PROTECTION**

Manual reset type for over current protection.

### **LIMIT SWITCHES**

Chain drive, screw type.

# IMPORTANT INSTALLATION INSTRUCTIONS



***WARNING - Failure to follow these precautions may result in severe personal injury or death.***

**1. READ AND FOLLOW ALL INSTALLATION INSTRUCTIONS.**

2. Door must be installed properly and balanced before installing the operator. An improperly balanced door can be hazardous and cause severe injury. Repairs to cables, spring assemblies and other hardware must be made by a qualified door installer. Operator damage may result if installed on an improperly working door. Safety features of operator will not function properly if door is out of balance.
3. Do not connect to electric power until installation is completed.
4. Remove or make inoperative any locking device unless operator is equipped with door lock interlock feature.
5. Remove all ropes, step plates and lift handles connected to the door before operating the garage door operator.
6. Installation and wiring must conform to local building and electrical codes.
7. Do not operate the transmitter or wall push-button unless the door is in sight.
8. Do not allow children to play with or in the area of the door and controls.
9. Do not place hands in area of pulleys, V-belt, sprockets, chain or rotating shafts.
10. Install warning placard on wall next to push-button.
11. Attach instruction booklet to wall near push-button.
12. Do not attempt to make electrical repairs without shutting off power to the unit.
13. Traffic patterns (vehicular and personnel) should be evaluated and proper safety equipment or push-button wiring installed to prevent damage or injuries.
14. Clutch should be adjusted according to procedure outlined on page 7 and checked periodically
15. Garage doors should *NEVER* be used as pedestrian doors.
16. Install the door operator at least 8 ft (2.44 m) or more above the floor. If the operator must be mounted less than 8 ft (2.44m) above the floor, the exposed moving parts must be protected by covers or guarding. Contact the manufacturer.
17. Verify that all labels for door and operator are in place, see page 18 for proper placement.
18. Install the Entrapment Warning Placard next to the door in a prominent location.
19. Locate the control station: (a) within sight of the door, (b) at a minimum height of 5 feet above floors, landings, steps, or any other adjacent walking surface and (c) away from all moving parts of the door.
20. For products having a manual release, instruct the end user on the proper operation of the manual release.

# PRELIMINARY INSPECTION

Before proceeding with the installation of your Raynor Jackshaft Operator, it is advisable that you check the following items:

## PACKAGING

Check shipping container for damage. Notify delivering carrier immediately.

## VISUAL INSPECTION

Visually inspect all parts of the operator for shipping damage.

Check the nameplate located on the powerhead to verify that the correct operator was shipped to you. Also check the power source available and compare it with the electrical data on the nameplate.

# INSTALLATION INSTRUCTIONS


Many of the problems related to electric operators are due to improper installation. The following installation procedures are recommended to minimize these problems.

## UNPACKING

This unit is shipped in one carton containing the operator itself, one drive and one driven sprocket, one length of chain, one control station, and one package of small hardware. Unpack carton being certain that all loose parts are removed before discarding packing material.


## MOUNTING POSITION

**⚠ WARNING:** This operator has been ordered for a specific mounting position. Because of differences in motor rotation, do not install operator in any position other than that for which it was ordered without first contacting the factory. See Fig. 1 below.




## INSTALL MOUNTING PAD

Begin installation by locating operator mounting pad in position shown (See Fig. 2). Use steel plate or heavy wood securely fastened to wall or framework.



## HANGING OPERATOR



During installation, keep in mind that it is best to have both the driving sprocket on the operator, and the driven sprocket on the door shaft, as close as possible to the bearings that hold the shafts in place. Assemble large, driven sprocket to door shaft as shown in Fig. 3 using the key provided in hardware package and tighten set screw. If door shafting is tubing, it should be plugged with 3/4" dia. solid bar for best results.



Place small drive sprocket on proper side of operator shaft as shown in Fig. 3. Drill holes in mounting pad to fit location of vertical slots in base angles of operator. Use cardboard template found in operator packaging for drilling rather than transferring dimensions. Lift operator into place, raising it so that the mounting bolts are against the bottom of the slots in the base angle to allow for maximum chain adjustment. Snug bolts enough to hold operator in place. The small drive sprocket will need to be aligned with large driven sprocket. Loosen set screw and move small sprocket along shaft to align vertically with large sprocket on door shaft. See Fig. 3. Place chain over door sprocket and operator sprocket. If chain is too long, remove required number of links and reassemble. Loosen mounting bolts and lower the operator to take up slack in chain. Be sure operator drive shaft is level and tighten mounting bolts. To prevent operator from moving out of position, install two bolts in horizontal slots of base angle. At this point, check all bolts and set screws for tightness.

## INSTALL DISCONNECT BRACKET

The operators are furnished with floor operated disconnect mechanisms to allow manual operation of door in an emergency. A wall mounted bracket is supplied with each operator to lock the disconnect chain in position while manually raising or lowering door. A length of chain is provided for use on standard side mounted units (position 1 and 5). **Note:** On operators with chain hoist, two disconnect chains are provided. One chain with extension spring disengages the brake mechanism and the other chain engages the chain hoist. See figures 4 and 5 for directions. Mount the bracket directly below the operator and thread the chain through slot in bracket. If the operator is mounted in any position other than 1 or 5, it may not be possible to use the chain provided. In such a case, use aircraft cable and pulleys to result in a smooth working disconnect. Best results are obtained when the cable travels a minimum distance in a straight line.



## CONNECT THREE BUTTON STATION

**Note:** When an external device, like a 3-button station, motion detectors, or photo eyes are required, you must use a wire type of CL2 or equivalent.

Your operator has been supplied with a standard three button station labeled open-close-stop. Mount three button station in sight of the door, at a minimum height of 5 feet and away from moving parts of the door. For proper connection of the three button station refer to wiring diagram in lid of operator. **At this time also mount warning placard supplied in hardware box next to three button station.**

## CONNECT ENTRAPMENT DEVICE

If other than constant pressure wiring type is required, you must connect a photo electric control, series 5000 by Vitector Fraba, model HAE00056 by Linear Corp., or Miller Electric reversing edge model ME with blue color band. For proper connection of device, refer wiring diagram found in lid of operator.



**WARNING:** Install the Photo Eye's **NO HIGHER** than 6" (15cm) above the floor.

| Monitored Reversing Devices |                           |                           |
|-----------------------------|---------------------------|---------------------------|
| Configuration:              | Connect to Sensor 1 Input | Connect to Sensor 2 Input |
| Electric Edge Only          | X                         | -                         |
| Photo Eye Only              | X                         | -                         |
| Photo Eye & Electric Edge   | Photo Eye                 | Electric Edge             |
| Photo Eye & Photo Eye       | Photo Eye 1               | Photo Eye 2               |



**WARNING:** Failure to connect a Raynor approved reversing device may cause severe injury or death



**WARNING:** Do not let children operate the door or play in the door area. Keep clear of the door it may move at any time without warning and keep door in sight at all times when it is moving.

## CONNECT TO POWER SUPPLY



**WARNING:** Before beginning any electrical hook-up, consult local wiring codes. This operator must be properly grounded. refer to wiring diagram found on inside of control box cover for power line, push-button, and reversing device connections.

Verify that line voltage and operator voltage shown on the cover are the same.

**Three Phase Power:** On units requiring three phase power, it is possible to run operator in wrong direction. To be certain motor is rotating in proper direction, manually


raise door to mid-position, by pulling disconnect chain down and locking it off in wall bracket as described above. With door in mid-position, release disconnect mechanisms. Press open button on control station and door should open. If the door does not open, press the stop button **IMMEDIATELY** and reverse any two of the three incoming power leads.

## LIMIT ADJUSTMENT and TESTING OPERATOR



**WARNING:** To avoid serious injury or death **always disconnect electrical power before adjusting limit switches.**

Operator has been supplied from the factory with constant pressure to open and close, it is advisable that you test the operator and set limit switches in this mode. Once correct rotation has been established, manually lower door to fully closed position. Set "close" limit nut at desired position by depressing limit nut keeper and turning limit nut toward "close" switch (see Fig. 6) until limit switch is activated (clicks). Raise door electrically to full open position and set "open" limit switch in manner as described above. After setting nuts in desired position, make certain that limit nut keeper engages grooves on limit nuts. When making fine adjustments, turn nut no more than 1/4 turn at a time. To stop door earlier, move nut closer to limit switch. To stop door later, back nut away from limit switch.



## MINIMUM WIRE SIZE FOR SINGLE-PHASE MOTORS

| Hp   | Volts | 0-25 Ft. | 50 Ft. | 100 Ft. | 150 Ft. | 200 Ft. |
|------|-------|----------|--------|---------|---------|---------|
| 0.33 | 115   | 14       | 12     | 10      | 8       | 6       |
|      | 230   | 14       | 14     | 14      | 14      | 12      |
| 0.5  | 115   | 14       | 12     | 10      | 8       | 6       |
|      | 230   | 14       | 14     | 14      | 14      | 12      |
| 0.75 | 115   | 12       | 10     | 8       | 6       | 4       |
|      | 230   | 14       | 14     | 14      | 12      | 10      |

## MINIMUM WIRE SIZE FOR THREE-PHASE MOTORS

| Hp   | Volts | 0-25 Ft. | 50 Ft. | 100 Ft. | 150 Ft. | 200 Ft. |
|------|-------|----------|--------|---------|---------|---------|
| 0.33 | 230   | 14       | 14     | 14      | 14      | 14      |
|      | 460   | 14       | 14     | 14      | 14      | 14      |
| 0.5  | 230   | 14       | 14     | 14      | 14      | 14      |
|      | 460   | 14       | 14     | 14      | 14      | 14      |
| 0.75 | 230   | 14       | 14     | 14      | 14      | 14      |
|      | 460   | 14       | 14     | 14      | 14      | 14      |

## CLUTCH ADJUSTMENT




**DANGER:** To avoid serious injury or death always disconnect electrical power before adjusting clutch.



**WARNING:** Do NOT over tension the clutch. The clutch must slip to prevent door damage or injury if the door hits an obstruction while moving.



**Caution:** If clutch does not slip, cables will unwind from drum and cause door to drop when obstruction is removed. After the final adjustment, make sure 1st nut and jamb nut are locked together.




**Note:** The clutch is set loose at the factory and must be adjusted in the field for proper sensitivity.

To adjust the clutch sensitivity, tighten the 1st nut until the operator will start to lift the door. If the clutch begins to slip, press the "stop" button and tighten nut again. Repeat this procedure until door travels smoothly in both directions to the fully open and closed positions. See Fig. 8.

After final adjustment, **make sure jamb nut is locked to 1st nut.** Using a wrench to hold the 1st nut, use a second wrench to tighten the jamb nut to the 1st nut, making sure nuts are locked together. See fig. 7

Additional adjustments may be required after a short breaking in period.





# LOGIC BOARD FUNCTIONS AND CONNECTIONS




Fig. 9

## AUXILIARY BOARD (OPTIONAL)




Fig. 10



# LOGIC BOARD PROGRAMMING

The logic board is programmed at the factory with constant pressure to open and close. Follow the instructions below to program the board for your application.

## Programming Notes:

1. Use the Open, Close and Stop buttons on the board when programming.
  2. **Open button** used to **increase time** or turn functions 'On' & 'Off'.
  3. **Close button** used to **decrease time** or **page** through choices.
  4. **Stop button** used to **continue** to next option and **end** programming.
1. To start the program mode, locate the program and stop button on the logic board (see figure 9), press and hold both program and stop buttons for 5 seconds.
  2. "**PROGRAMMING FIRMWARE**" will display briefly followed by "**PROGRAMMING CONFIGURATION**", then "**WIRING MODE**" will display. There are three options to choose from as shown below.  
  
**NORMAL SR5** - 3 button momentary contact on open, close, and stop with 1 second delay on open and close with provisions for connection of a reversing device(s).  
  
**CSTP OPN/CLS RD** - Constant pressure to open and close.  
  
**CSTP CLS ONLY RC** - 3 button momentary contact on open and stop, constant pressure to close.
  3. Select the wiring type by using the **close button** to page through the wiring modes. Press the **stop button** to **continue** to the next option.
  4. "**SENSOR 1 TYPE**" will display, there are two options to choose from, "**PHOTO EYE**" or "**ELECTRIC EDGE**". Use the **close button** to page through the choices. Press the **stop button** to **continue** to the next option. When using **RD** or **RC** wiring, photo eye's or edge must be selected even though they are not required.

Note: The photo eye or an electric edge must be monitored.

5. "**SENSOR 2 TYPE**" will display, there are three options, "**NONE CONNECTED**", "**PHOTO EYE**", or "**ELECTRIC EDGE**". Use the **close button** to page through the choices. Press the **stop button** to **continue** to next option.

Note: The photo eye or an electric edge must be monitored.

If wiring type is RC or RD, this is the end of the programming steps. If SR5 wiring is selected continue to step 6.

6. "**TIMER TO CLOSE**", this will display only if there is a jumper connected on **JS3** or a switch connected to **J3 & J4** of the logic board. The timer to close can be set from 10 seconds to 240 seconds in 1 second intervals. Use the open and close buttons on the board to set the time. Press the **stop button** to **continue** to the next option.
7. "**AUX INPUT 1 TYPE**" will display. There are five options to choose from as shown below. Use the **close button** to page through the choices. Press the **stop button** to **continue** to next option.

**NONE CONNECTED** - No device required

**REVERSING (N.C.)** - Non-monitored, normally closed reversing device.

**REVERSING (N.O.)** - Non-monitored, normally open reversing device.

**VENTILATION (N.O.)** - A normally open contact, such as a carbon monoxide detector, may be used to open the door for ventilation. The door can be opened to a determined height by setting the open run time. See #8.

**FIRE STATION (N.O.)** - A normally open contact, such as a pull cord, can be used to open the door. The door will fully open and then close after a determined time has been set. The door will only time out and close, if opened from the auxiliary input. See #9.

8. If "**VENTILATION (N.O)**" was selected, the distance the door is to open needs to be set. The display should read "**OPEN VENT TIME**", the distance is determined by the number of seconds the door will open. This is done in 1 second intervals from 3 to 30 seconds. Use the open and close buttons on the board to set the time. Press the **stop button** to **continue** to the next option.
9. If "**FIRE STATION TIMER (N.O)**" was selected, the time to close needs to be set. "**FS: TIME TO CLOSE**" will display. This is done in 10 second intervals from 60 to 900 seconds. Use the open and close buttons on the board to set the time. Press the **stop button** to **continue** to the next option. **Note:** Can not be used in conjunction with a "Timer to Close".
10. "**AUX INPUT 2 TYPE**" will display, this is used for a second auxiliary device Repeat steps 7 through 9 if a second auxiliary contact is required.
11. "**MIDWAY STOP**", this allows the door to stop midway through the open cycle. If a midway stop is not required, select "**OFF**". If the midway stop is required, select "**ON**". Press the **stop button** to **continue**.
12. If a midway stop was selected, "**MIDWAY TIME**" will display, the distance is determined by the number of seconds the door will open. This is done in 1 second intervals from 3 to 30 seconds. Use the open and close buttons on the board to set the time. Press the **stop button** to **continue** to the next option.
13. If there is no auxiliary board, then programming the logic board is complete. If there is an auxiliary board, then continue through steps 14 - 16.
14. "**LIGHT ON TIME**" will display, this is used to turn on a light and shut off a light after a determined amount of time. This is done in 10 second intervals from 10 to 240 seconds. Use the open and close buttons on the board to set the time. Press the **stop button** to **continue** to the next option.
15. "**CLOSE WARNING LIGHT**" will display, this is used to activate a warning light a determined amount of time before the door times out and closes. If no warning light is required, select "**OFF**". If a warning light is required, select "**ON**". Press the **stop button** to **continue**.
16. If a warning light is "**ON**", "**WARNING TIME**" will display. The time is set in 1 second intervals from 3 seconds to 10 seconds. If there is a timer to close, the close warning light time must be set lower than the timer to close time. Use the open and close buttons on the board to set the time. Press the **stop button** to **end** programming.

## **SPECIAL PROGRAMMING INSTRUCTIONS**

The maximum run timer and reverse limits option are factory set and you are not required to set these in the initial set up. However, in the event that you need to modify either one of these options, use the instructions below.

### **Maximum Run Timer**

To help prevent damage to the operator, it is supplied with a maximum run timer (factory set at 40 seconds) with a maximum run time of 120 seconds.

To change factory default, press and hold the stop button and program button until you enter the programming mode. Once in the program, release both buttons. Then press and hold the program button for approximately 30 seconds, or until an asterisk shows up on the screen. Then release the program button. You can now use the stop button to advance through the program until you see the maximum run timer. Use the open and close buttons to adjust the time. Once finished, use the stop button to advance the rest of the way through the program.

### **Reverse Limits & Motor Direction**

For ease of changing the operator position, it has been supplied with a "reverse limits" option. If you need to switch the open and close limit switches, press and hold the stop button and program button until you enter the programming mode. Once in the program, release both buttons. Then press and hold the program button for approximately 30 seconds, or until an asterisk shows up on the screen. Then release the program button. You can now use the stop button to advance through the program until you see the reverse limits option. Use the open and close buttons to select "yes" or "no" (factory default is "no"). Once finished, use the stop button to advance the rest of the way through the program. When selecting the reverse limits option, this will also reverse the motor wiring for you.

# **USER AND IMPORTANT SAFETY INSTRUCTIONS**

## **WARNING - To reduce the risk of severe injury or death:**

1. **READ AND FOLLOW ALL INSTRUCTIONS.**
2. Never let children operate or play with door controls. Keep the remote control (where provided) away from children.
3. Personnel should keep away from a door in motion and keep the moving door in sight until it is completely closed or opened. **NO ONE SHOULD CROSS THE PATH OF A MOVING DOOR.**
4. Test the doors reversing features at least once a month per instructions supplied with reversing device. If limit switches require adjusting, reversing devices must also be re-tested. Failure to adjust the operator properly, may cause severe injury or death.
5. For products having a manual release, if possible, use the manual release only when the door is closed. Use caution when using this release when the door is in the open position. Weak or broken springs may cause the door to fall rapidly, causing severe injury or death.
6. **KEEP DOORS PROPERLY OPERATING AND BALANCED.** See Door Manufacturer's Owner's Manual. An improperly operating or balanced door could cause severe injury or death. Only have a trained door systems technician make repairs to cables, springs and other hardware.
7. Only use Raynor approved reversing device as explained on front cover of this installation booklet. Failure to use a Raynor approved device may cause severe injury or death.
8. **SAVE THESE INSTRUCTIONS.**

## **OPERATING INSTRUCTIONS:**

### **Operating the 3-Button Control Station:**

1. Press OPEN button (*The door should move in the open direction*).
2. Press STOP button (*The door should stop*).
3. Press the CLOSE button (*The door should move in the close direction*).
4. Release the close button and the door should stop if set up for constant pressure (*The door should continue to close if set up for momentary contact and has an approved monitored reversing device*).
5. Press stop button (*The door should stop*).

### **How to verify limit switches are adjusted properly:**

1. Press open button and allow door to fully open. The limit should be adjusted so that bottom of door is about an inch above the bottom of the header.
2. Press close button and allow door to fully close. The door should just hit the floor and stop. If close limit is set too low, the door may hit floor and keep trying to run. This can cause damage to door and operator. If door does not completely seal against floor, the problem may be with the floor being un-even.

*If the limits are not set properly, and need adjustment, remove power and adjust limits (Refer to page 6).*

### **TEST THE ENTRAPMENT PROTECTION DEVICES:**

1. Open the door.
2. Place an obstruction in the path of the photo eyes or electric sensing edge.
3. Press the CLOSE button. The door should not close if photo eyes are functioning. If a sensing edge is installed, the door should close onto the obstruction and reverse to fully open.
4. Remove the obstruction.
5. Press CLOSE button. The door should close.

If door did NOT reverse from obstruction, check entrapment devices.

# PERIODIC INSPECTION AND MAINTENANCE

Your Raynor electric door operator was designed to give dependable service with a minimum amount of maintenance. After proper installation and adjustment, by a qualified installer, little is required in the way of maintenance except for periodic inspection and lubrication as follows:

## LUBRICATION

All Raynor operators are supplied with continuous rated motors and under normal conditions require no oiling.

## INSPECTION AND ADJUSTMENTS



**WARNING: Repairs and adjustments to the door or operator should only be made by a qualified door installer.**

1. Inspect and tighten (if necessary) all bolts and nuts.
2. Periodically check that all labels shown on page 18 are installed. If labels are missing, contact your nearest Raynor dealer.
3. Adjust clutch as shown in Fig. 7, if necessary. Adjustment may be required after a short break-in period.
4. If necessary, adjust limit nuts as described in Fig. 6.
5. Check V-belt for wear and replace if necessary. Also check V-belt tension (about 1/2 inch deflection when applying pressure with finger). Adjust tension by loosening motor bolts and moving motor toward the rear of the operator.

6. Check manual operation of door. Refer to installation instructions 800, page 5972558-1 for guidelines.

7. Test all reversing devices once a month for proper operation.

8. Test all accessories that may have been supplied with the operator to ensure they are working properly.




**CAUTION: Do not reset overload until problem is identified. Damage to door and operator or personal injury could result if cause of tripping is not corrected.**

**9. Manual Reset Overload:** The overload is properly sized, at the factory, for normal door operation. If overload trips, manually check mechanical operation of door and operator to be certain both work freely.

**Single Phase:** When overload trips, it cuts power to the entire unit. To reset, press reset button on outside of control box.

**Three Phase:** When overload trips, it cuts power to the 24 volt control circuit only. To reset, open control box cover and press red reset button.



## ON BOARD STATUS LIGHTS

| Status Light                           | Definition  |
|--|---|
| 1. Stop (D14)                          | On = Stop button connected and working.<br>Off = Stop button pressed or NOT connected.  |
| 2. Open (D12)                          | On = Open button sending signal (pressed)<br>Off = Open button is not sending signal.   |
| 3. Close (D13)                         | On= Close button sending signal (pressed)<br>Off = Close button is not sending signal.  |
| 4. Sen 1 (D20)                         | On = Sensor 1 hooked up & working<br>Off = Sensor 1 activated, or has malfunctioned.  |
| 5. Sen 2 (D21)                         | On = Sensor 2 hooked up & working/ or sensor 2 not programmed.<br>Off = Sensor 2 activated, or has malfunctioned.   |
| 6. I-Lock (D24)                        | On = Chain hoist interlock circuit is open. (chain hoist is pulled, malfunctioned, or jumper is missing for non-chain hoist units)<br>Off = Chain hoist circuit is closed. (normal operation) |
| 7. I-Lock (D23)                        | On = Lock interlock circuit on TB-2 is open. (Jumper is missing or interlock circuit device has been activated)<br>Off = Lock interlock circuit on TB-2 is closed. (normal operation)         |
| 8. Single (D15)                        | On = Single button activated.<br>Off = Single button not activated.   |
| 9. Non -Monitored (D18)<br>Aux Input 2 | On = Non monitored circuit is closed.<br>Off = Non monitored circuit is open.   |
| 10. Non-Monitored (D19)<br>Aux Input 1 | On = Non monitored circuit is closed.<br>Off = Non monitored circuit is open.   |
| 11. Limit 1 - Open (D16)               | On = Limit switch is activated.<br>Off = Limit switch is not activated.   |
| 12. Limit 2 - Close (D17)              | On = Limit switch is activated.<br>Off = Limit switch is not activated.   |



## LCD DISPLAY MESSAGES

| Display                | Definition   |
|------------------------|--|
| "Locked Out"           | The LCD display will read "locked Out" when either the on board chain hoist interlock, or the door interlock, on terminal block 2 is activated. These connections will have a jumper when not required.  |
| "TCS Paused"           | When in Timer to close mode (TCS), and door is in the open position, if the stop button is pressed while timer is still counting down it will pause the timer until either the open or close button is pressed.  |
| "Lock Bar Detected"    | This message will display whenever the open button is pressed and the limit nut does NOT come off the close limit switch with in a certain amount of time. If the door is stuck down for any reason, the open cycle will shut down to save damage to the door.     |
| "Close in XX sec."     | When in timer to close mode, and the door is in the open position, the display will read the amount of time in seconds that is remaining until door closes. You can activate the stop button to pause this countdown.  |
| "Sensor 1 activated"   | This message will display anytime the board is not receiving a signal from the sensor 1, when close button is pressed. Whether it is not connected, activated, or has malfunctioned.   |
| "Sensor 2 activated"   | This message will display anytime the board is not receiving a signal from the sensor 2, when close button is pressed. Whether it is not connected, activated, or has malfunctioned. If no sensor is required on sensor 2, select "None Connected" in the program. |
| "Aux 1 activated"      | This message will display anytime the board is not receiving a signal from the Aux 1 when close button is pressed. Whether it is not connected, activated, or has malfunctioned. If no sensor is required on Aux 1, select "None Connected" in the program.        |
| "Aux 2 activated"      | This message will display anytime the board is not receiving a signal from the Aux 2 when close button is pressed. Whether it is not connected, activated, or has malfunctioned. If no sensor is required on Aux 2, select "None Connected" in the program menu.   |
| "At Open Limit"        | This message will display anytime the board is receiving a signal from the open limit switch and the open button is pushed.  |
| "At Close Limit"       | This message will display anytime the board is receiving a signal from the close limit switch and the open button is pushed.   |
| "Aux Board Connected"  | This message will display when the operator is powered up, and the auxiliary contacts board is connected to the main board via wiring harness.   |
| "Partially Open"       | This message will display anytime the door is not on the fully open or close limit switch.   |
| "Opening Door Running" | This message will display when the door is running in the open direction.  |
| "Closing Door Running" | This message will display when the door is running in the closed direction.  |

# COMMERCIAL OPERATOR TROUBLESHOOTING LIST

| SYMPTOM  | PROBABLE CAUSE   | PROBABLE SOLUTION   |
|--|--|---|
| Operator will NOT respond to any commands.   | 1. No power to Operator.   | <ol style="list-style-type: none"> <li>1. Connect Operator to power source.</li> <li>2. Check voltage at L1 &amp; L2 for single phase and at L1, L2 &amp; L3 for three phase.</li> <li>3. Check for blown fuse or tripped circuit breaker.</li> </ol>   |
|  | 2. Overload protector tripped in operator.   | <ol style="list-style-type: none"> <li>1. Reset and check for cause. Located externally on single phase, and internally located on three phase.</li> </ol>  |
|  | 3. Display on logic board reads "Locked Out".  | <ol style="list-style-type: none"> <li>1. ChainHoist interlock switch is activated, has malfunctioned, or the jumper is missing on non chain hoist units. See "Logic Board Functions and Connections" on page 8.</li> <li>2. Interlock device on Terminal Block 2 has malfunctioned or jumper is missing. "Logic Board Functions and Connections".</li> </ol> |
| Operator only works with constant pressure on close button.  | 1. Reversing device not hooked up, or not working properly.  | <ol style="list-style-type: none"> <li>1. See wiring diagram for proper connection of reversing devices.</li> </ol>   |
|  | 2. Wiring mode set for RC or RD wiring.  | <ol style="list-style-type: none"> <li>1. Set wiring mode to SR5 momentary operation. See "Logic Board Functions and Connections" on page 8.</li> </ol>   |
|  | 3. Reversing device is activated.  | <ol style="list-style-type: none"> <li>1. Remove obstruction.</li> </ol>  |
|  | 4. Improper programming of reversing device.   | <ol style="list-style-type: none"> <li>1. Make sure the logic board is programmed for the correct reversing device. If using a photo eye, make sure program is set for photo eye. Same goes for an electric edge. See "Logic Board Functions and Connections".</li> </ol>   |
| Radio control will not work.   | 1. Weak battery.   | <ol style="list-style-type: none"> <li>1. Replace battery.</li> </ol>   |
|  | 2. Incorrect hook up.  | <ol style="list-style-type: none"> <li>1. Refer to wiring diagram for proper connection.</li> </ol>   |
| Operator does NOT shut off at fully open or closed position.   | 1. Limit nuts not properly adjusted.   | <ol style="list-style-type: none"> <li>1. See limit switch adjustment in installation instructions.</li> </ol>  |
|  | 2. Limit drive train is broken or inoperative.   | <ol style="list-style-type: none"> <li>1. Replace chain, check drive mechanism, and re-adjust limit switches.</li> </ol>  |
|  | 3. Limit switch is damaged.  | <ol style="list-style-type: none"> <li>1. Check limit switch operation and replace if necessary.</li> </ol>   |
| Door closes when open button is pressed and door opens when close button is pressed.   | 1. Three phase power is connected out of phase.  | <ol style="list-style-type: none"> <li>1. Interchange any two incoming power supply leads.</li> </ol>   |
|  | 2. Open & close buttons not wired correctly.   | <ol style="list-style-type: none"> <li>1. Refer to wiring diagram for proper connection.</li> </ol>   |
| Door will open most of the way, but stops short of fully open, and the open button must be pressed again to fully open the door. | <ol style="list-style-type: none"> <li>1. Maximum run timer has timed out. The default setting is 40 seconds. For larger doors, maximum run time may need to be set higher.</li> </ol>         | <ol style="list-style-type: none"> <li>1. See instructions for setting of Maximum Run Timer.</li> </ol>   |
| There is a delay between when the open or close button is pressed, and when the door begins to move.                             | <ol style="list-style-type: none"> <li>1. This is normal operation. This delay is in place to keep the door from reversing instantly and to eliminate stress on rollers and cables.</li> </ol> | <ol style="list-style-type: none"> <li>1. Normal operation, no solution.</li> </ol>   |
| Sensors are lined up but still not sending signal to the logic board.  | 1. Sunlight is blocking the receiving photo eye.   | <ol style="list-style-type: none"> <li>1. Move photo eyes away from opening, or swap the receiver and transmitter to keep the receiver out of the sunlight.</li> </ol>  |
|  | 2. Faulty photo eyes.  | <ol style="list-style-type: none"> <li>1. Replace photo eyes.</li> </ol>  |




# Common Mistakes that could damage or disrupt a ControlHoist 2.0 Logic Board

## High Voltage Wiring


High voltage wires must never be ran in the same conduit as low voltage wiring (which includes push-button wiring, interlock devices, and any 24v accessory device). High voltage wires supplying power to the operator can create a magnetic field around themselves. This magnetic field can disrupt the low voltage signals and disrupt the normal operation of the operator. When running high voltage conduit, try to run the low voltage wires at least 12" or more away from the low voltage wires to avoid any magnetic interference.

## Hooking Up Accessories

1. There is 24VAC power available at terminals 15 & 16 on the logic board. This power source can be used to power an external device such as a motion detector. These 2 terminals are **only to be used to power a device**. If either of the terminals are shorted to any other terminals on the board, it will damage the boards.




2. The 24VAC power terminals, 15 & 16, are rated for 500mA (.5 amps) or 12 watts of power consumption. Hooking up a device that draws more than the rated power consumption will damage the logic board. Verify power consumption of the device(s) before installing. You may have to power the device from an external power source, using only the contacts of the device to activate the operator.
3. The common on the main board is its own unique common to itself, and should be connected to dry contacts only! Never induce voltage into the signals (open, close, aux1 aux2, etc.) or commons of the board.



Dry Contact - A dry contact means there is no energy being supplied to the contact. It is completely passive and isolated. The example above shows a dry contact being used to activate a signal between common and aux12.


## Auxiliary Board (when supplied)

1. The contacts on the auxiliary board are rated for 3 amps. If the device you are activating draws more than the rated 3 amps, you will need to drive a relay that has the correct rating. Then, use the dry contacts of that relay to activate the device. If more than 3 amps of power is being consumed through the auxiliary board, then damage to the board may occur.
2. There is a 14 pin connector on the main board which allows you to connect an auxiliary board to the main board. Take care to never short these pins together or damage to main board will occur. Always disconnect power before attempting any type of work on any garage door opener.



↑  
**14 Pin Connector**

# LABEL PLACEMENT FOR JACKSHAFT OPERATORS



- \* Label Supplied With Operator
- \*\* Label Supplied With Raynor Door

NOTE: Placement of Labels may vary from what is shown.